



UPSTools Plus

- User's Manual -

Compatible with UPS series:

- SDU (5 ÷ 10 kVA)

INTRODUCTION

UPSTools Plus is a utility program, compatible with Windows systems, for the configuration of UPS devices.

To use *UPSTools Plus*, copy the "*UPSToolsPlus.exe*", "*UPSToolsPlus.pdf*" and "*usbdl.dll*" files to a folder of your PC. Then, run *UPSToolsPlus.exe*.

Symbols used in this manual:


- | | | |
|--|-------------|--|
|  | Danger | Indicates information that must not be ignored.
Failure to follow these indications may cause serious damage to the UPS, the batteries or the load. |
|  | Warning | Indicates important information.
Failure to follow these indications may result in UPS malfunctioning. |
|  | Information | Provides notes and useful suggestions for the User. |

Parallel UPS configuration

-  In a parallel system, the configuration sent to a single UPS (either Master or Slave) is automatically transmitted, unless otherwise specified, to all the UPS devices.

MENU	4
FILE	5
CONNECTION	6
VIEW	7
COMMANDS	9
PASSWORD	11
ABOUT	11
SETTINGS	12
BASIC	12
<i>OPERATING MODE</i>	13
<i>OUTPUT</i>	14
<i>GENERAL</i>	15
<i>ENERGYSHARE</i>	16
<i>TIMER</i>	17
ADVANCED	18
<i>GENERAL</i>	19
<i>COMMUNICATION SPEED</i>	20
BYPASS	21
<i>ONLINE</i>	22
<i>ECO MODE</i>	23
BATTERY	24
<i>NOMINAL</i>	24
<i>GENERAL</i>	25
<i>CAPACITY</i>	25
BATTERY TEST	26
<i>SCHEDULING TIME TEST</i>	27
EXTERNAL I-O	28
<i>I/O CARD MODEL</i>	28
<i>INPUT CONTACT</i>	29
<i>OUTPUT CONTACT</i>	30
AVAILABILITY OF THE FUNCTIONS	32

MENU



- ① New configuration file:**
Creates a new UPS configuration using default values.
- ② Open configuration file:**
Opens a configuration file (.gcf) previously saved on a disk.
- ③ Save configuration file:**
Saves a configuration file (.gcf) to disk, containing all the settings selected in the various program tabs.
- ④ Download configuration file from UPS:**
Downloads the configuration of the UPS at the moment of connection, which is then displayed on the various program tabs.
- ⑤ Upload configuration file to UPS:**
Loads the configuration displayed in the various program cards to the UPS.
- ⑥ Connect to UPS:**
Activates the PC↔UPS connection.
- ⑦ Disconnect from UPS:**
Deactivates the PC↔UPS connection.
- ⑧ Insert password for service level:**
Allows a password to be entered to access the Service level.

FILE

New

Creates a new UPS configuration using default values.

Open

Opens a configuration file (.gcf) previously saved on a disk.

Save

Saves a configuration file (.gcf) to disk, containing all the settings selected in the various program tabs.

Save as...

Saves and renames a configuration file (.gcf), containing all the settings selected in the various program cards.

Download

Downloads the configuration from the UPS that is currently connected, which is then displayed in the various program cards.



The command is active only if the UPS is connected (see *Menu* → *Connection* → *Connect*).

Upload

Loads the configuration displayed in the various program tabs to the UPS.



The command is active only if the UPS is connected (see *Menu* → *Connection* → *Connect*).



After confirming this command, the UPS configuration is overwritten with that present and cannot be restored. Before giving the command, make sure that all the values set are correct.

Exit

To exit the program.

CONNECTION

Connect

Activates the PC↔UPS connection by the USB port.


Once the operation is finished, the status of the UPS is indicated in the status bar on the bottom left.

 For the PC↔UPS connection, use a USB cable 2.0 (A-B, m-m).

Disconnect

Deactivates the PC↔UPS connection.

Once the operation is finished, the UPS disconnected status is indicated in the status bar on the bottom left.



VIEW

Settings

Displays the identification data, nominal data, and the type of UPS connected.

The command is active only if the configuration has already been downloaded (see *Menu* → *File* → *Download*).

Nominal Data	
UPS identification	
UPS model	RT1K06
UPS code	
Firmware version (mC)	SWM070-01-02
Firmware version (DSP)	SWD068-01-01
Nominal data	
Nominal power (VA)	6000
Nominal power (W)	6000
Nominal battery voltage (V)	180
Nominal battery capacity (Ah)	6
UPS type	
UPS type	On Line and Line Interactive
I/O configuration	Monophase/Monophase
Batteries number for bench	15
Battery benches	1

Statistics

Displays the values of the internal counters and timers of the UPS.

The command is active only if the configuration has already been downloaded (see *Menu* → *File* → *Download*).

Counters	
Nr. battery working	1
Nr. bypass work	0
Locks due to short circuit	0
Locks due to overload	0
Locks due to overtemperature	0
Other locks	0
Timers	
Total working time	3h 12m
Total time on battery	0h 4m
Work time with load > 75%	0h 0m

Service date

Displays the dates of the most recent activities carried out by the Service team and the months/days remaining before the next scheduled maintenance.

The command is active only if the configuration has already been downloaded (see *Menu* → *File* → *Download*).




Service Date	
First installation	20/09/2017
Last battery change	Not initialized
Time to service	
UPS alarm	Months --- Days ---
Battery alarm	Months --- Days ---

Close

COMMANDS

 All commands are active only when the UPS is connected (see *Menu* → *Connection* → *Connect*).



Battery test

Activates the battery test. The command is carried out only if the UPS is powered by the mains, the load is powered by inverter and the batteries are at least 90% charged.

 In a parallel battery configuration system, the command must be sent to the Master UPS.

Test panel

Allows for a UPS panel test to be carried out.

Synch power on


If sent to a UPS belonging to a parallel system, the command simultaneously switches on all of the UPS devices. To be used to power the system on when the load already connected, in order to avoid overload problems which may occur if all the UPS devices are not switched on simultaneously.

-  The command is carried out only if the UPS is on Stand-by.
-  The service level password is required to execute this command.



Set UPS time


Allows for changing the UPS clock and date.



PASSWORD

Service password

Allows a password to be entered to access the Service Level.



ABOUT


Help

Opens this manual.

SETTINGS

BASIC

Setting the main operating parameters of the UPS.



OPERATING MODE

Operating mode

Mode On line ▼

Delay power off (sec)

Mode

Select the desired operating mode [Default → Online].

Online	This mode ensures maximum load protection and the best waveform output quality.
Eco mode	This is the mode with the lowest UPS consumption and; therefore, the most efficient. The load is normally powered by bypass and, if the mains power is out of the tolerance range, the UPS changes to Online mode. Approximately 5 minutes after the mains tolerances are restored, the load is automatically switched over to bypass.
Smart active	In this mode, the UPS, based on statistics regarding the quality of the input network, decides independently whether to work in Online or Eco mode.
Standby Off	In this mode, the UPS is used as an emergency device. When there is mains power the load is not powered while, if there is a black-out, it is powered by the inverter using the batteries, with a less than 0.5 second intervention time (see also "Delay power off").
Frequency converter	In this mode, the UPS can work with an input frequency of 50Hz and an output frequency of 60Hz or vice versa. In this case, automatic bypass is disabled.

 In a parallel system the **Frequency converter** mode set on a single UPS (either Master or Slave) is NOT transmitted automatically to all the UPS devices. Therefore, it is necessary to set this mode on all of the parallel system's UPS devices.

Delay power off

If the operating mode is set as "Stand by off", configure the delay (expressed in seconds, from 0 to 65534) between the restoration of mains power and the switching off of the load [Default → 0sec.].

OUTPUT

Output

Nominal voltage (V) (220 - 240)

Nominal frequency (Hz)

Nominal voltage

Set the desired output voltage of the UPS [Default → 230V].

Nominal frequency

 The service level password is required to configure this parameter.


Select the desired output frequency (50 or 60 Hz) of the UPS [Default → 50Hz].

 The output nominal frequency must always be properly selected.

 The configuration of a new frequency set occurs only when the UPS is powered. After any changes are made, the UPS must be completely switched off and then switched back on.

 Incorrect configuration of the output frequency may cause damage to the loads connected to the UPS. Before configuring the parameter, check the nominal frequency of the loads connected to the UPS.

GENERAL



General

Autorestart Delay (sec) 5

Auto power off

Buzzer reduced

Auto restart

If, during battery operation, the UPS switches off due to end of autonomy, or due to a remote shutdown command, or due to self-shutdown, when power is restored, the UPS automatically switches on if the function is enabled; however, it remains in stand-by if the function is disabled [Default → Function ENABLED].

If the function is enabled, set the delay (expressed in seconds from 0 to 255) between the restoration of power and the switching on of the UPS [Default→5 sec].

Auto power off

If, during battery operation, the percentage of the load powered by the UPS falls below the 5% threshold (load switched off or disconnected), after 40 seconds the UPS automatically switches off if the function is enabled; the UPS continues to function normally via battery if the function is disabled [Default → Function DISABLED].

Buzzer reduced

If the function is disabled, the buzzer sounds in all cases provided for (see UPS manual). If, however, it is enabled with bypass operation, the buzzer remains switched off for the first 3 seconds: in this way, brief bypass transfers are not reported [Default → Function ENABLED].

ENERGYSHARE

The UPS may be equipped with an outlet socket that allows for the automatic disconnection of the load applied to it in certain operating conditions.

EnergyShare

EnergyShare off Never ▼

EnergyShare time (sec) 3

EnergyShare off

Set the event that causes the automatic cut-off of the EnergyShare socket [Default → Never].

Never	EnergyShare socket always connected
Battery working	Switch off in battery operating mode
Line present	Switch off if the input line is present
Battery low	Switch off if battery power is low
User overload	Switch off if a load exceeds the threshold defined by the user (see <i>Settings</i> → <i>Advanced</i> → <i>General</i> → <i>Maximum load</i>)
Overload	Switch off due to overloading
Temperature Ok	Switch off if the UPS temperature is good
External input on	Switch off if the signal at the "Input 3" remote input is active (see <i>Settings</i> → <i>External I-O</i> → <i>Input contact</i>)
No lock	Switch off in the absence of safety blocks
No fault/alarm	Switch off in the absence of alarms
Normal status	Switch off in case of normal operation
Battery % low ⓘ	Switch off due to discharged battery
Stand-by	Switch off if the UPS is in Stand-by
Always	EnergyShare socket always disconnected

ⓘ When **Battery % low** is selected, the parameter **EnergyShare time** indicates the percentage of battery capacity [range 0% -100%] below which the EnergyShare socket is automatically cut off.

EnergyShare time

Set the delay (expressed in seconds between 0 and 65535) between the occurrence of the selected event and the automatic cut-off of the EnergyShare socket [Default → 3].

ⓘ In a parallel system this parameter is NOT transmitted automatically to all the UPS devices. Therefore, it must be configured on each individual UPS.

TIMER

 The service level password is required to configure these parameters.

You can schedule the automatic switch on and/or the automatic switch off of the UPS at a specific hour.

Timer

<input checked="" type="checkbox"/> Timer on	(hh:mm)	<input type="text" value="07:00"/>
<input checked="" type="checkbox"/> Timer off	(hh:mm)	<input type="text" value="20:30"/>

 Check the time set on the UPS before enabling any timer.

 The times of switch on and switch off have to be expressed in **hh:mm** (eg. 07:30).

Timer on

Set the time when the UPS have to be switched on automatically.

 If the mains is not present at the time set for automatic switching on, the UPS stays in stand-by status and ready to switch on when the mains will be present.


Timer off

Set the time when the UPS have to be switched off automatically.

ADVANCED

Setting the advanced operating parameters of the UPS.

 The service level password is required to configure these parameters.



GENERAL

General

<input type="checkbox"/> Autonomy limitation	Limit (sec)	<input type="text"/>
<input type="checkbox"/> Maximum load	Load (%)	<input type="text" value="0"/> <input type="button" value="▲"/> <input type="button" value="▼"/>
<input type="checkbox"/> Enable auto system on		

Autonomy limitation

If the function is enabled, it is possible to set a maximum battery operation time (“Limit” - expressed in seconds and between 1 and 65534); when this time has expired the UPS automatically switches off even if the autonomy of the batteries has not been exhausted. [Default → Function DISABLED]

 In a parallel system this function is NOT transmitted automatically to all the UPS devices. Therefore, it must be configured on each individual UPS.

Maximum load

If the function is enabled, the load percentage may be set (“Load” - between 0 and 103%); if this is exceeded the UPS signals a maximum load fault [Default → Function DISABLED].

Enable auto system on

When the function is enabled and the UPS is powered, it will automatically switch on-line without first changing to Stand-By and without having to press the ON button [Default → Function DISABLED].

COMMUNICATION SPEED

Communication speed

Slot 1 (bps)

Slot 1

To set the desired speed for “*Communication slot 1*” [Default→1200].




Speed configuration takes place only when the UPS is powered. After a change is made the UPS must be completely switched off and then switched back on.
If the value 9600bps is set, the PRTK code of the corresponding communication port becomes GPSE19601...

BYPASS

Setting the bypass operating parameters.

 The service level password is required to configure these parameters.



ONLINE

Setting the bypass parameters with the UPS in Online mode (see *Setting* → *Basic* → *Operating mode*).

On line	
Mode	Enabled high sensibility ▼
Frequency tolerance (± %)	5 ▼
Minimum threshold (V)	180
Maximum threshold (V)	264

Mode

Select the bypass line mode for transitional events and in emergency conditions [Default → Enabled high sensibility].

Enabled high sensibility	Switching to bypass enabled with high sensitivity intervention (inverter voltage waveform control active).
Enabled low sensibility	Switching to bypass enabled with low sensitivity intervention (inverter voltage waveform control not active; inverter voltage RMS value control active)
Disabled /Inverter sync.	Switching to bypass disabled. Output frequency synchronized with input frequency.
Disabled /Free running	Switching to bypass disabled. Output frequency NOT synchronized with input frequency.
Active in stand-by	When the UPS is on stand-by, the load connected to the output is powered via the bypass line.



If the **Active in stand-by** mode is activated, the UPS output is always powered.

Frequency tolerance

Select the percentage that determines the frequency range within which the UPS can synchronize the output sinusoid with the input sinusoid [Default → 5%].

Minimum threshold

Set the minimum accepted bypass voltage threshold for use of the same; it is possible to set values from 180V to 220V in increments of 1V [Default → 180V].

Maximum threshold

Set the maximum accepted bypass voltage for use of the same; it is possible to set values from 240V to 264V in increments of 1V [Default → 264V].

ECO MODE

Setting bypass parameters when the UPS is in Eco mode (see *Settings* → *Basic* → *Operating mode*).

Eco mode	
Sensibility	<input type="text" value="Normal"/>
Minimum threshold (V)	<input type="text" value="200"/>
Maximum threshold (V)	<input type="text" value="255"/>

Sensibility

Select the sensibility of the bypass line quality control [Default → NORMAL].

Minimum threshold

Set the minimum bypass voltage range threshold accepted for Eco mode operation; below this threshold, the UPS switches to Online mode. It is possible to set values from 180V to 220V in increments of 1V [Default → 200V].


Maximum threshold

Set the maximum bypass voltage range threshold accepted for Eco mode operation; above this threshold, the UPS switches to Online mode. It is possible to set values from 240V to 264V in increments of 1V [Default → 255V].

BATTERY

Setting the internal battery parameters of the UPS.

 The service level password is required to configure these parameters (except of “Battery low time”).



NOMINAL

Nominal

Battery voltage (V)	180
Battery number	15

Battery voltage

Displays UPS internal battery voltage (field cannot be changed).

Battery number

Displays the number of UPS internal batteries (field cannot be changed).

GENERAL

General

Battery low time (min)	<input type="text" value="3"/>	<input type="button" value="↑"/> <input type="button" value="↓"/>
Autorestart voltage (V)	<input type="text" value="177"/>	<input type="button" value="↑"/> <input type="button" value="↓"/>

Battery low time

Set the estimated runtime (expressed in minutes between 0 and 255), below which the UPS signals the battery low alarm [Default → 3].

Auto restart voltage

Set the minimum battery voltage value (between 200 and 260 volts) above which the UPS automatically restarts [Default → 236].

CAPACITY

Capacity

Internal battery (Ah)	<input type="text" value="6"/>
External battery (Ah)	<input type="text" value="0"/>
Total	<input type="text" value="6"/>

Internal battery

Displays the capacity (Ah) of the UPS internal batteries (field cannot be changed)

External battery

Allows for insertion of the capacity (Ah) in case of an external UPS battery box.


Total

Displays the total capacity of the batteries, calculated by adding the internal capacity and the capacity of the external battery box (if any).

BATTERY TEST

Setting the execution mode of the battery test.

 The service level password is required to configure these parameters.



SCHEDULING TIME TEST

Scheduling time test

Automatic battery test

Every Time (hours)

Every Time (days) 2 at 19 : 15 ▼

Every Month-day at : ▼

Scheduling time test

Automatic battery test

Every Time (hours)

Every Time (days) at : ▼

Every Month-day 28 at 22 : 00 ▼

Automatic battery test


If the function is enabled, the UPS automatically carries out the battery tests [Default → Function ENABLED]. It is possible to set the frequency with which the UPS run the test (time between tests and the next) choosing from 3 options:

- 1) execution of the test every *n* hours ("*Time*" - expressed in hours and between 1 and 273) [Default → 40].
- 2) execution of the test every *n* days at a fixed time ("*Time*" - expressed in days and between 1 and 39; "*a*" - time of the test in the format "hh:mm" between 00:00 to 23:45 in step of 15 minutes).
- 3) execution of the test every established day of the month at a fixed time ("*Month-day*" – day of every month between 1 and 28; "*a*" - time of the test in the format "hh:mm" between 00:00 to 23:45 in step of 15 minutes).


EXTERNAL I-O

Configuration of the programmable inputs and outputs present on the MultiCOM 384 accessory.

-  The service level password is required to configure these parameters.
-  In a parallel system these parameters are NOT transmitted automatically to all the UPS devices. Therefore, they must be configured on each individual UPS.



I/O CARD MODEL



Multicom 384 [4 out]

To configure the contacts of the MultiCOM 384.

INPUT CONTACT



Input 3 mode

Select the function to be associated with the "Input 3" input remote control. In presence of a low active signal at the input (see also *Settings → External I-O → Delay*), the UPS carries out the associated function [Default → Load on bypass].

No operation	No function
System on	UPS start-up
System stand-by	UPS switch-off
System on/stand-by	UPS Start-up and Switch-off
GE mode	Generator group mode (see also <i>Settings → External I-O → Battery charger off & Disable bypass</i>)
Battery test	Battery test
Load on bypass	Load on bypass
Eco mode	UPS in Eco mode
Stand-by Off Mode	UPS in Stand-by Off mode
SWBAT status	External Battery Switch Status

Battery charger off

This option can only be enabled if Input 3 is set to GE mode; if the function is enabled, in presence of a high active signal at input, the UPS battery charge is switched off [Default → Function DISABLED].

Disable bypass

This option can only be enabled if Input 3 is set to GE mode; if the function is enabled, in presence of a high active signal at input, use of the bypass line is disabled [Default → Function DISABLED].

Delay

Set the min time (expressed in milliseconds and between 0 and 5000) of the impulse at the Input 3 input, below which the UPS does not consider the signal active [Default → 480].

OUTPUT CONTACT

Output contact	
Output 3 mode	Inverter locked ▼
Output 1 mode	Battery low ▼
Output 2 mode	Battery working ▼
Output 4 mode	Load on bypass ▼

 Read carefully MultiCOM384 user manual to properly configure it. Keep the rotary switches of the MultiCOM 384 in the default configuration in order to have the right association between the outputs and the events selected with the software.

Output 3 mode

Select the event to be associated with "Output 3" (RL3 of the MultiCOM 384). The contact opens when the set event occurs [Default→Inverter locked].

Output 1 mode

Select the event to be associated with "Output 1" (RL1 of the MultiCOM 384). The contact closes when the set event occurs [Default→Battery low].

Output 2 mode

Select the event to be associated with "Output 2" (RL2 of the MultiCOM 384). The contact closes when the set event occurs [Default→Battery working].

Output 4 mode

Select the event to be associated with "Output 4" (RL4 of the MultiCOM 384). The contact closes when the set event occurs [Default→ Load on bypass].

Battery low	End of charge pre-alarm
Battery working	Battery operating mode
Load on bypass	Load powered by bypass
Inverter locked	Inverter stage locked
Lock or fault	Lock or fault level alarm
Any alarm	Any alarm
Overload	Overload
Overtemperature	Overtemperature
Replace battery	Batteries to be replaced
External input	Signal active at "Input 3" remote input is (see <i>Settings</i> → <i>External I-O</i> → <i>Input contact</i>)
Load on inverter	Load powered by inverter
Output powered	Output powered
Bypass bad	Bypass line out of tolerance range
Eco mode	Operation in Eco mode
Manual bypass	Operation by manual bypass
UPS ok	Normal operation
Backfeed protection 	BYPASS SCR FAIL alarm active
Inverter asynch.	Inverter not synchronized with the bypass line
Mains line bad	Input line out of tolerance
Battery fail	Batteries not present, to be replaced or end of discharge
Output switch open	Output switch open

Selecting **Backfeed protection**, the contact can be used to control an external circuit breaker for the bypass line in case of a backfeed alarm.



In this case, changes the operation logic of the UPS because, being able to disconnect the bypass line, the load is powered by the inverter also in the presence of a BYPASS SCR FAIL alarm.

AVAILABILITY OF THE FUNCTIONS

 Check the UPS firmware version before using the functions described in this manual.

All the functions described in this manual are available in the following firmware revision:

mC	FW070-0101 or higher
DSP	FW068-0101 or higher

